

GET THE MOST OUT OF YOUR RAMPAGE BOARD BY VIEWING OR
DOWNLOADING OUR TUTORIALS AND VIDEOS!
CHECK THEM OUT AT WWW.GOAPEONLINE.COM

After your marker is switched on, you may notice the Blue and Red LED's may be ON. This alert occurs when your eyes are on and there is no ball loaded in the breach. Assuming your hopper is properly attached and filled with paint, the most likely cause is that you have not yet switched on your electronic hopper or you just need to give your hopper a "shake" so a ball feeds properly. Once a ball is properly loaded, the Breach alert LED's will go out and switch to the Firing Mode display indicating you're ready to fire.

Although the Rampage board offers the most comprehensive set of marker controls available, your Rampage™ board requires NO programming and comes pre-configured with the most optimal default settings. Once installed, just switch it on and GO PLAY!

QUICK STARTUP OF THE RAMPAGE™ BOARD

The Rampage™ board is a high-performance upgrade for your marker. We recommend using a fresh battery before any major tournament or event to ensure peak performance. To change your battery, please refer to your original owners manual.

USING YOUR NEW RAMPAGE™ BOARD

WARNING - ALL PERSONS WITHIN RANGE OF A PAINTBALL MARKER MUST USE PROPER EYE PROTECTION. NEVER DISASSEMBLE A MARKER WHILE IT IS UNDER PRESSURE WITH COMPRESSED AIR OR CO2. ALWAYS REMOVE THE AIR SOURCE BEFORE WORKING ON YOUR MARKER. ALWAYS FOLLOW THE MANUFACTURER'S INSTRUCTIONS WHEN USING OR WORKING ON YOUR MARKER. NOT POSSIBLE DAMAGE TO YOUR MARKER. USE THIS PRODUCT AT YOUR OWN RISK.




RAMPAGE™ USERS GUIDE



Powered by RAMPAGE!

Firing Mode
Semi — One Shot per Trigger Pull
Burst — x rounds fired per Trigger Pull (x= 2 to 5)
Reactive — x rounds fired per Trigger Pull (x= 1 to 5)
Full Auto — Fires continuously while the trigger is held
Rampage 1—Definable Ramping (defaults to a burst ramping mode)
Rampage 2—Definable Ramping (defaults to a full-auto ramping mode)
PSP3—Three shots in Semi-Automatic then transitions to 3 Round Burst. Returns to Semi-Automatic after 1 Second of inactivity.
NXL—Semi-Automatic for the first 3 shots, then Full Automatic on the 4th pull and hold. Resets to Semi-Automatic after 1 second of inactivity.



Firing Mode
Semi
Burst
Reactive
Full Auto
Rampage 1
Rampage 2
PSP3
NXL

Your Rampage™ board comes with 8 base firing modes. To change modes, tap the Power Button. Each time the Power Button is pressed, the LED display will change indicating what mode is currently selected. Each firing mode has a corresponding LED identification:

SELECTING YOUR FIRING MODE

Full Power (8.5V and above / flash and click)
Medium-Full Power (7.5V - 8.5V / flash and click)
Medium Power (6.5V - 7.5V / flash and click)
Low Power (6.5V and below / solid and beep)



STARTING YOUR RAMPAGE™ SHOCKER BOARD
To start your new Rampage™ Shocker board, simply press and release the power button on the back of the maker. You will be in firing mode. Your Rampage Shocker board also comes with a built in battery level indicator that can be used when starting your marker. To use the battery level indicator, press and hold the power button. While holding the power button, the LED's will indicate the strength of your battery in bar graph form. When you release the power button, you will be in firing mode.



For technical support or help with your existing product, please contact

SUPPORT@GOAPEONLINE.COM

OR

VISIT OUR FORUMS AT WWW.GOAPEONLINE.COM

Advanced Paintball Electronics
P.O Box 125
Odessa, Florida 33556-0125

PRODUCT WARRANTY

Rampage boards are covered against manufacturer defects for a period of 1 year. We DO NOT warrant the solenoid OR external wiring. If you have any questions, please ask before you purchase our product.

VOIDING YOUR WARRANTY

- Improper Installation (we can install your product for you)
- ANY alteration to the Circuit Board or code
- Improper use, misuse, abuse or physical damage
- Mishandling and/or Electro-Static-Discharge (ESD) damage

WWW.GOAPEONLINE.COM

VER 1.1

COPYRIGHT © 2007 APE